

CRAVE

WINK+

PRODUCT INSTRUCTIONS

BEFORE YOU START

WINK+ is designed for external use only and the product will warm up during use.

QUICK START GUIDE

ON

CHANGE PATTERN

OFF



Hold for 2 Seconds

Low Battery Indicator: Wink+ will pulse 3 times to indicate low battery



Optional Silicone Sleeve

The silicone sleeve can be used to provide a softer texture at the tip and minimize warming.



Apply pressure evenly on both side

Silicone Sleeve Removal Tip


The silicone sleeve is made to fit snug. To remove, push or pull using the bottom edge of the sleeve.

USB CHARGING

1

2

3



Allow 2.5-3 hours to fully charge.




CHARGING



Fully charged


SPECIAL NOTE: Use only CRAVE supplied charger. Please allow 1-2 minutes for charger to light up red.

PRODUCT CARE



CLEANING TIP:

Always keep product fully assembled during cleaning. Product is waterproof only when assembled.



PRODUCT SAFETY



Not for vaginal or urethral insertion.



Not for anal use.



To avoid fire hazard, use only CRAVE supplied charger.