

CRAVE

TEASE

NECKLACE INSTRUCTION BOOKLET

*Welcome to CRAVE Pleasure Jewelry,
where intimacy meets self-expression.*

Please be sure to read this instruction booklet and, in particular, the product safety information prior to use.

Table of Contents

ABOUT TEASE	<i>7</i>
INSIDE THE BOX	<i>8</i>
USB CHARGING	<i>11</i>
HOW TO USE	<i>12</i>
HOW TO WEAR	<i>14</i>
PRODUCT CARE	<i>17</i>
PRODUCT WARNING & CAUTION	<i>18</i>
FAQS	<i>20</i>
CONNECT WITH US	<i>21</i>
PLEASURE GUARANTEE	<i>22</i>



*Tease is a statement necklace
and an external vibe.*

*Tease shown in silver. It is also available in 24k gold.

About TEASE

Designed to provide beautiful experiences for your pleasure, Tease has been in development for over ten years at CRAVE. Tease was created to elevate intimate self-expression as part of our Pleasure Jewelry Collection.

Crafted from hand-polished stainless steel with nickel-free electroplating, Tease is fully waterproof and submersible. Offering up to 30 minutes of runtime on the highest setting, it is rechargeable via USB-C. Designed with convenience in mind, the included pouch and charging cable allow you to travel effortlessly—wherever love or lust may lead you.

Inside the box

One fully assembled and ready-to-wear Tease necklace

Which includes:

Tease necklace chain

Tease vibrator pendant



Inside the box


4-Pocket storage pouch



Instruction booklet



Charging cable



Before your first use

- Charge your Tease vibe for 2 hours for a full charge.
- Ensure the vibe is secured tightly onto the necklace chain.
- The product will not turn on without being fully assembled with the chain.


USB Charging

CHARGING INSTRUCTIONS


1



2



3



POWER INDICATOR

▲ FULLY CHARGED

▲ CHARGING


Tease will pulse 3 times to indicate low battery.

How to use

QUICK START GUIDE



Tighten the ends so it is fully touching the metal connector



Press **▲** to turn on.

Press **▲** to cycle through 4 modes: low, medium, high, and wave.

Quickly double click **▲** for TURBO mode.

Hold **▲** for 2 seconds to turn off.


Tease will pulse 3 times to indicate low battery.

Desire more power?

Quickly double click **▲**
for TURBO mode

How to use

EXPLORE MORE SENSATIONS



The Tease necklace is designed for external use only and can be used in various erogenous zones: the neck, nipples, scalp, lower back, inner thighs, lower abdomen, and feet.

Since all bodies are different, please be sure to check with your partner to see if this feels right to them.



CAUTION

The chain is intended for wear not to support and/or facilitate insertion into the body.

How to wear

ADJUSTABLE CHAIN



The Tease is designed to be worn as an adjustable necklace—from choker style 14" to princess length 18."

Feel free to adjust your necklace to match your personal style and preference.

How to wear

WEAR SOLO OR LAYERED



Wear the Tease as a striking statement necklace—bold, minimalist, and unlike anything else in your jewelry box. Style it layered or solo, depending on your mood.

NOTE: Before using and wearing out, ensure the vibe is secured tightly onto the chain.

Caring for your necklace

Product care



Clean with warm soap and water or water-based cleaner before and after use.



Keep product assembled during cleaning. Tease is not waterproof when disassembled.



When reassembling the vibe, do not over tighten the vibe without the chain.



Do not use silicone-based lube or products, as they will damage the button.

BATTERY HEALTH TIPS

For optimal battery life, unplug when fully charged and recharge soon after use. Leaving products fully discharged for over a month can cause permanent battery damage.

Product warnings & precautions

Do not insert the Tease anywhere in the body to avoid serious injury.

 **WARNING**



Not for urethral or vaginal insertion.



Not for anal use.



Keep out of reach of children.



If you use this product with partner(s), please share these warnings with them.

 **CAUTION**



The chain is intended for wear **not** to support and/or facilitate insertion into the body.



For hygienic purposes, ensure the product is properly cleaned before and after use.



To avoid injury, exercise caution while wearing Tease necklace— like all jewelry — as they can get caught on external objects. Do not wear while operating heavy machinery.



Only charge CRAVE products with CRAVE-supplied chargers. Using non-CRAVE chargers can significantly damage your product and create a safety hazard.

Frequently asked questions

Can I insert the necklace into the body?


No, the Tease is designed for external use only. It is not intended for insertion into any part of the body.

How do I clean the necklace?

Before cleaning, ensure the Tease is fully assembled, as it is not waterproof when the vibrator is separated into two parts.

Rinse with soap and warm water, and wipe with a soft towel. You may use alcohol or most other disinfectants without damaging the product.

Why won't my necklace turn on?



The product will not turn on without detecting the metal connector

Without full assembly of the chain and vibrator, the unit will not turn on. If the vibe pulses three times, please charge as it indicates a low battery.

Connect with us

SHARE YOUR EXPERIENCE

Share your style and connect with our community of fierce individuals owning their pleasure. We are here to celebrate you.

Tag us on Instagram @lovecrave with hashtags #lovecrave #pleasurejewelry

Or leave a review at [LOVECRAVE.COM](https://www.lovecrave.com)

HAVE A QUESTION?

We may have the answer here:
Support.lovecrave.com

Or email us at support@lovecrave.com

Pleasure Guarantee

All CRAVE products are covered by our Pleasure Guarantee: 1 year warranty against manufacturer's defects and 5 years of extended support from the date of purchase.

Any products experiencing manufacturing defects (non-cosmetic) within 1 year of purchase are covered by our warranty. We can repair the product or replace the defective unit at no charge.

Our extended coverage applies to all products for 5 years from the purchase date. We'll cover 50% of the retail cost for a new replacement product.

Only products purchased through CRAVE and authorized retailers are eligible. To initiate a warranty claim, please contact hi@lovecrave.com and include your order number in your request.

LOVECRAVE.COM

 @LOVECRAVE